Connect your Raspberry to the Wi-Fi using Wi-Fi Settings panel in Ubuntu.

Then find IP by running in terminal command:

\$ ifconfig

From this moment you no need to connect display, because now you can SSH your board from the development laptop.